

FOR TORPEDO 50, 100 OR 400 USERS (TORPEDO BOTTLES WITHOUT A BLACK BREATHER VALVE INSTALLED):

IF YOU ARE USING THE CLEAR LID, YOU WILL NEED TO CREATE A HOLE IN IT TO AERATE THE BOTTLE.

1. Use a 1/8" drill bit or 1/8" nail to create a hole from the outside to the inside of the lid. Make sure the hole is straight and perpendicular to the surface.



FOR TORPEDO VERSA 200 AND 500 USERS (USING THE BLACK BREATHER VALVE):

TO INSTALL THE NEW BREATHER VALVE, FOLLOW THESE STEPS:

1. Remove the old breather valve and clean off any remaining adhesive from the valve.
2. Apply a small amount of food-grade silicone adhesive onto the underside of the new breather valve head. Insert into the hole, making sure the valve is fully inserted in the bottle per the Drawing. The top of the valve should be flat against the top of the bottle.
3. Clean up any silicone that comes out the sides of the valve using a wet rag.
4. Allow adhesive to set for at least 24 hours prior to using/washing.



HOW TO CLEAN

HAND WASH YOUR TORPEDO BOTTLE, STRAW, PLUG, BITE VALVE AND LID EVERY TIME YOU USE IT AND BEFORE INITIAL USE.

Hand Wash Instructions

When cleaning by hand, it is not necessary to remove accessories.

1. Fill Torpedo bottle with soapy water.
2. Use one hand to cover the holes on top of the bottle.
3. Shake bottle vigorously.
4. Rinse and repeat.

Straw: Hand wash straw in lukewarm water only. Use a long thin brush to clean tube. Hot water or the dishwasher will damage straw material.